


Inflatable Tripod Tent



Sizes Available

3M x3 M

4M X 4M

5M X 5M

ASSEMBLY INSTRUCTIONS - INFLATION

Recommended procedure below. For safety reasons it is recommended that 2 persons set up any inflatable tent. Ensure area is free from any sharp objects and overhead objects.



1 Remove the Inflatable Tent from the protective cover.



2 Roll out the Inflatable Tent.



3 Lay the Inflatable Tent out flat.



4 Inflatable Tent Accessories*
Layout your walls and awnings and confirm positioning.



5 Attach the accessories using zips.



6 Each leg on the Inflatable Tent has a valve. Select valve to attach pump, screw inflation valve closed and leave cap off. On all other valves screw tight and fix cap.



7 Connect the pump to selected inflation valve and begin inflation.



8 During the inflation process raise legs into the center until all legs are upright.



9 Ensure all legs are lined up and the Canopy is centered. Check frame is firm.



10 Fix stakes and guide ropes or attach sandbags.

IMPORTANT NOTES:

Check the wind and weather conditions before commencing construction.

Ensure you have the correct ground fixings for your application.

When the tent is in use, do not leave your tent unattended.



Over pressure relief valve system.
DO NOT TOUCH.

ASSEMBLY INSTRUCTIONS - DEFLATION

Recommended procedure below. For safety reasons it is recommended that 2 persons set up any inflatable tent. Ensure area is free from any sharp objects and overhead objects.



1 Remove the stakes and guide ropes or detach the sandbags



2 Ensure the area is clear of persons. Ensure the area is dry and clean. Unscrew all valves to deflate the tent.



3 Remove all air from the tubes.



4 Fold tent up neatly laying the Canopy and legs on top of each other. Roll up tent.



5 Pack the dry and clean inflatable tent into the protective cover.

IMPORTANT NOTES:

Ensure the Canopy and wall fabrics are completely dry before packing down and fitting the protective cover.

During transport do not put heavy items on top of the tent.

ACCESSORIES included



Stakes.



Hand Pump.



Sand Bags x 4.

ACCESSORIES available



Electric Pump.